



## CRASHGARD®

SAND BARREL LID ATTACHMENT GUIDE

### STEP 1



Tools required: rubber mallet and a pry bar. Fill the barrel with sand to the desired weight. Once filled, seat the lid on the barrel with the gap facing the installer.

### STEP 2



Insert the pry bar between the lid and the barrel. Steadily press down on one side of the lid. Have a second person apply a steady downward force on the lid on the opposite side of the pry bar.

### STEP 3



While pressing downward, pull the pry bar downward, flexing the lid outward and pull the lid lower on the barrel. Keep applying the downward pressure.

### STEP 4



Using the hammer, tap the barrel where the barrel is bulging and preventing the lid from fitting. This should allow the lid to lower onto the snapping point of the barrel.

### STEP 5



Repeat with all CrashGard in the array. The CrashGard array is now ready to protect the intended fixed object.